

DPF-15A1GB

Premium 15" **HD** DIGITAL PICTURE FRAME



User Guide

Table of Contents

Introduction	3
Main Features	3
Getting Started	4
Package Contents	4
Installing your unit	4
Connecting to a PC	4
Controls	5
Using your Remote Control	5
Inserting Memory Cards	6
Main menu	6
Viewing Pictures	7
Changing the orientation for one picture	8
Zoom	8
Browsing Thumbnails	8
Watching video	9
Listening to MP3 music	9
Playing a slideshow with music	10
Viewing Text	11
Using the EDIT option	11
Copying and Deleting Files	11
Using the SETUP option	12
Language setup	12
Clock Set option	13
Alarm Set Option	14
Changing the slideshow speed	14
Video setup	15
Technical Support	16
Frequently asked questions	16
Service and Warranty	18
Your warranty	18
Specifications	19
Maintenance and Precaution	19
Cleaning the LCD screen	20
Regulatory Compliance	22
CE Declaration of Conformity	22
Federal Communications Commission (FCC) Notice (U.S. and Canada Only)	22
Commission Fédérale de la Communication (FCC Déclaration)	23
End-of-Life Disposal	23

Introduction

Congratulations on your purchase of GoldLantern Digital Picture Frame. Model No.: DPF-15A1GB.

Before operating the unit, please read this manual thoroughly, and retain it for future reference. This manual will help you use many of the exciting and useful features that will make your Digital Picture Frame viewing more enjoyable.

This Digital Picture Frame lets you view digital pictures directly from your camera's memory cards or the internal memory. You will be able to create a slideshow using multiple transition effects or display one picture at a time. No computer, digital camera or Internet connection is required.

This Digital Picture Frame is compatible with the following popular memory card formats: CompactFlash®, SD™, XD, MultiMediaCard™, and Memory Stick®.

It can also read files stored on a USB Flash drive using the USB host port.

Main Features

Displays digital pictures (JPEG) without a computer

Simply insert a compatible memory card into the Digital Picture Frame to show photos, play MP3 music or supported video files

Compatible memory cards include Secure Digital Card (SD), , Multimedia Card (MMC), Memory Stick (MS), XD Cards & Compact Flash

Able to read files located on a USB Flash drive

Instantly plays MP3 music with the integrated speakers.

Instantly plays MPEG1, Motion JPEG /DIVX/ XVID/ MS MPEG4 AVI files stored on supported memory cards*.

Supports up to 12 Mega Pixels image file. (JPEG format).

Compatible with most digital cameras' stored JPEG images and motion JPEG files.

Includes a credit card style remote control

Bright TFT active matrix LCD screen.

Automatic slide show with multiple transition effects.

Plays slide show with MP3 music on the background.

User-friendly on-screen display lets you access all controls easily.

*Video files may not play properly if stored on a low speed card.

Getting Started

Package Contents



Digital Picture Frame and stand



User Guide



AC/DC Adapter



Remote Control



USB Cable

Installing your unit

Open the package and remove the protective foam. Remove the protective sleeve from the unit.

Install the Digital Picture Frame stand as the back of the unit.

Plug in the AC adapter into power outlet. Plug the other end into the unit.


After the content is stored on the target flash media; insert the media into the correct slot.

Turn power to ON position via the ON/OFF switch.

Connecting to a PC

The Digital Picture Frame has a USB port for connection to a PC (USB Slave) and a second USB port for connection to other devices such as a Flash Drive, USB card reader, or a camera (USB Host).

Controls



Using your Remote Control

The following table briefly describes the remote control functions

Button	Description
Power	Turn on/off/AV Out
Photo	Access your photo files
Music	Access your music files
Video	Access your videos files
Combo	Start the slideshow
Time	Display the time/ Calendar
Mute	Mutes volume
Menu	Displays the main menu
Enter	Select highlighted item
VOL +/-	Adjusts volume
Arrows	Navigate on screen
▶/	Play/ pause



Inserting Memory Cards

The Digital Picture Frame is compatible with the following memory cards:

Secure Digital™ Card (SD)

MultiMedia™ Card (MMC)

Memory Stick™

CompactFlash™ (CF) Card

XD Picture Cards

Insert the memory card with the front label facing AWAY from you. Do not force the memory card into the memory slot. If you are not able to easily insert the memory card completely, you may have inserted it the wrong way.

Note:

The Digital Picture Frame will ONLY recognize digital pictures stored in JPEG format. Digital pictures stored in other formats will be ignored by the device.

Make sure you have at least one picture stored on the memory card. The frame will not function properly without a stored picture.

You also can use a USB flash drive in the exact same way as you would use a memory card. Simply copy files on the flash drive and insert it at the right side of the unit in the USB Host plug.

Main menu

Upon turning on the Digital Picture Frame, the slideshow will automatically start. Press the “MENU” button to show the following menu:



This screen will allow you choose the type of media to play. Use the left and right arrows to move inside the menu and then press “Enter” to continue

Note: In all menus, pressing the “Menu” button will bring you back to the main menu


Function	Description
Picture	Play photos in slideshow
Music	Play MP3 audio
Combo	Play slideshow with audio
Movie	Play movies
Text	Play text data on the display
Edit	Copy/Delete, Brightness, Contrast, Saturation
Setup	Set System Menu

Viewing Pictures

Make sure you have at least one picture on your memory card/ USB flash drive or internal memory. When this is done:
 Highlight the “PHOTO” option from the main menu and press “ENTER”
 Select the desired flash media. (SD/xD/CF/MS/USB/ Internal Memory)




A list of available pictures will be displayed. Use the up and down arrows to highlight the desired file and press “Enter” to continue



The slideshow will start

Once a slideshow is playing or a picture is being shown, press the ENTER button. (In a slideshow, using the remote control press "ENTER" twice to pause then change settings on a specific picture). The following menu will appear:



Changing the orientation for one picture

Use the rotate function to change the picture orientation to either portrait or landscape.

Zoom

Choose the Zoom function to magnify the image. Repeat this operation several times to further zoom in.

Browsing Thumbnails

Choose the thumbnail option on the menu (the icon with 9 bullets points) and you will be able to browse though your pictures in thumbnail format.

Watching video

The Digital Picture Frame supports the following video formats:
 Motion JPEG (AVI): video format used by most digital cameras
 MPEG1, DIVX/XVID/ MPEG4 (AVI)


Make sure you have at least one video on your memory card or your USB flash drive. When this is done:
 Choose the "MOVIE" option from the main menu and press "ENTER"
 Select the desired flash media. (SD/xD/CF/MS/USB/Internal Memory)

A list of available videos will be displayed. Use the up and down arrows to highlight your required file and press "Enter" to continue



The video will begin playing



Once a movie is playing, press the ENTER button on the remote control. The following menu will appear:



Listening to MP3 music

Make sure you have at least one MP3 file on your memory card/USB flash drive or internal memory. When this is done:
 Choose the "MUSIC" option from the main menu and press "ENTER"
 Select the desired flash media. (SD/xD/CF/MS/USB/Internal Memory)

A list of available songs will be displayed. Use the up and down arrows to highlight your required file and press “Enter” to continue



Playing a slideshow with music

Ensure you have at least one picture on your memory card/USB flash drive or internal memory. Additionally, you must have one MP3 file saved on the selected memory card/USB/Internal Memory. When this is done:


Choose the “COMBO” option from the main menu.

Select the desired flash media. (SD/xD/CF/MS/USB/Internal Memory)

A list of available pictures will be displayed. Use the up and down arrows to highlight your required file and press “Enter” to continue

The slideshow will start while playing the first available song on the media

Once audio-slideshow has started, press the ENTER button on the remote control. The following menu will appear:



Viewing Text

Make sure you have at least a text file in ASCII format on your memory card or your USB flash drive. When this is done:
 Choose the "TEXT" option from the main menu.
 Select the desired flash media. (SD/xD/CF/MS/USB/ Internal Memory)
 A list of available text files will be displayed. Use the up and down arrows to highlight your required file and press "Enter" to continue
 The text will be displayed
 The up and down arrows can be used to scroll through the on screen text.

AV Out:

Press the "POWER" button at the main menu after connected with other displayer, it will display on other monitors.

Caution: Please do not insert USB when the digital photo frames connecting computer!

Using the EDIT option

With the EDIT function you can Copy/Delete files as well as control the Color Setup.

Copying and Deleting Files

To copy and delete files on your memory card/ USB drive or internal memory:

Copy:

Choose the "EDIT" option from the main menu.

Select the desired flash media that you want to copy from. (SD/xD/CF/MS/USB/ NAND Internal Memory)

A list of available files will be displayed. Use the up and down arrows to highlight your required file and press the right arrow to highlight the desired file.

Repeat for all files that you want to copy

Press the "Menu" button to go back to the main display

Choose the "EDIT" option from the main menu.

Select the desired flash media that you want to copy to (SD/xD/CF/MS/USB/ Internal Memory)

Press the “MENU” button to display the Copy and Delete menu. Select the Suitcase icon and your file(s) will be copied.

Delete:

Choose the “EDIT” option from the main menu.

Select the desired flash media that you want to delete from. (SD/xD/CF/MS/USB/ NAND Internal Memory)

A list of available files will be displayed. Use the up and down arrows to highlight your required file and press the right arrow to highlight the desired file.

Repeat for all files that you want to delete

Press the “MENU” button to display the Copy and Delete menu. Select the Garbage Can icon and your file(s) will be deleted

Using the SETUP option

The following options can be changed by using the “SETUP” option from the main menu:

Menu Function	Description
Language	Includes Simplified Chinese, English, German, French and Spanish
Picture set	Includes the speed of automatic slide show, picture play mode two items.
Startup Set	Includes Mode select, Picture, Music, Movie and Play list
Video set	Screen brightness, contrast and color setup
Default set	Recover the factory default setup

Language setup

You can change the default language used by the menu as follows:

Choose the “SETUP” option from the main menu.


Choose the “ABC” option.



Use the up and down arrows to select your preferred language

Clock Set option


You can change the clock as follows:
Choose the "SETUP" option from the main menu.
Choose the "Clock Set" option.



Use the right and left arrows to highlight the desired parameters and the up and down arrows to change the time/ date.
Press ENTER when finished

Alarm Set Option

Set the alarm for a specific time by:



Choose the "SETUP" option from the main menu.

Choose the "Alarm Set" option

Use the right and left arrows to highlight the desired parameters and the up and down arrows to change the time/ date

Ensure that "mode" is turned to "ON"

Press ENTER when finished

Changing the slideshow speed

You can change the slideshow speed as follows:

Choose the "SETUP" option from the main menu.

Choose the "Slideshow Model" option.




Video setup

You can change some of the display parameters in order to improve the picture quality. Those parameters are: Brightness, Contrast and Color
Choose the "SETUP" option from the main menu.

Choose the "Video Set" option.

Select the parameter to change and press "Enter"



Use the right and left arrows to change the value

Startup setup

You can change the startup from main menu to slideshow or calendar as you like, choose the option, and then select what you like.

Technical Support

Frequently asked questions

1) Q: Why do my photos take so long to load?

A: Generally the higher the resolution of the photo, the longer it will take to load. Resizing your photos to a lower resolution will quicken the processing time.

2) Q: How do I store music files?

A: First, use a personal computer and popular audio editing software to convert your music to MP3 format. The Digital Picture Frame will only play MP3 files so all Windows Media Player™ and/or iTunes™ files will have to be converted first. You can use a card reader or your digital camera to transfer those files to your memory card.

3) Q: How come the Digital Picture Frame does not show some of my photos?

A: The Digital Picture Frame is designed to show photos following the same camera industry standards format as digital cameras. This format is a JPEG format. Images, such as web images, scanned images, or photos in RAW format, are not stored according to camera industry standards and therefore cannot be displayed correctly on the Digital Picture Frame. Please use your PC applications to convert such images into standard JPEG format before viewing them on the Digital Picture Frame.

4) Q: If I keep showing the same photo for a long time, will it damage the LCD screen?

A: No. The Digital Picture Frame can display the same photo continuously for a long time. But it is recommended not to show the same picture continuously for more than 1 month.

5) Q: Why I can not show my video?

A: Please pay more attention about your video format, we can support most MP4 format and AVI format file.

Troubleshooting

Symptom	Cause	Corrective Actions
Digital Picture Frame doesn't power on	The POWER connector to the unit is not securely inserted.	Make sure you connect the AC adapter to the frame properly. When you connect the AC adapter to the frame and power up the unit, even without a memory card, you should see a blank screen. If you don't see the lit screen, check if the power is connected to the Digital Picture Frame and make sure it is securely attached.
No Start-up screen	Memory card is not inserted correctly.	Insert a supported memory card
No photo, videos or mp3 files on the memory card	Card is wrongly inserted	Verify if the way you inserted the card is correct. Make sure the front label of the memory card is facing AWAY from you. Do not force the memory card into the slot.
The File doesn't play	Incompatible File Format	Make sure there is at least one supported photo file on the memory card.
		Compatible Photo format: Compatible Photo format: JPEG
		Compatible Music format: MP3
		Compatible Video format: Motion JPEG/ DIVX/ XVID/ MS JPEG4 (AVI), MPEG1

Service and Warranty

Your warranty

Dear Consumer,

Thank you for purchasing a GoldLantern Digital Picture Frame, which has been designed and manufactured to the highest quality standards.

If, unfortunately, this product malfunctions, GoldLantern guarantees free of charge labor and replacement parts during a period of 12 months from the date of leave factory.

This guarantee applies granted that the product is handled properly and has been used only as intended, in accordance with its operating instructions and upon presentation of the original receipt, indicating the date of purchase, retailer's name, model and serial number of the product.

The warranty may not apply if:

The documents have been altered or made illegible;

The model or serial number on the product has been altered, deleted, removed or made illegible;

Unauthorized service organizations or persons performed repairs, product modifications, or alterations to the unit.

Damage is caused by means not relating to the design or manufacturing of the product including water or fire, lightning, misuse or neglect.

Please note that this guarantee is void in any case that modification have been made in order for the product to comply with local or national technical standards which apply in countries for which the product was not originally designed or manufactured for.

In case your product is not working correctly or is defective, please call GoldLantern, LLC Customer Service at 949-595-2181 or send an email to information@goldlantern.com

Escape clause:

Below are not for free service bound:

Without warranty card or invoice. Fall short of warranty provision.

Serial No. was broken, lost or unconformity with unit.

LCD panel damaged, broken or leak liquid crystal.

Specifications

Type	GoldLantern Digital Picture Frame
Resolution	1024 x 768
Power Supply	12 V
Consumption	6 Watts
Working Temperature	-20 to +65 degrees
Luminosity	350cd/m ² max.
Contrast	300:1
Viewing Angle	70/70/70/40 (CR=10)
Response Time	25ms
Display Mode	4:3
Photo Changing Interval	Fast, Slow, Normal
File Format	JPEG, MP3, MPEG1, AVI (JPEG Motion, DIVX/XVID/MS MPEG4)
Photo Size	12 Mega Pixels
Current	AC110—240V (50HZ—60HZ)
Cards	SD/MMC/MS/CF/XD/USB
USB ports	USB Host, USB Slave
Start-up	Slideshow/main menu/ calendar
Package Contents	Digital Picture Frame AC/DC Adapter User Guide Remote control USB Cable

Maintenance and Precaution

The Digital Picture Frame is for indoor use only.

To reduce the risk of fire or electric shock; do not expose this appliance to rain or moisture.

Do not block the ventilation holes on the back of the Digital Picture Frame at any time.

Keep your Digital Picture Frames out of sunlight. Direct sunlight may cause damage.

Do not open the case of the Digital Picture Frame. There is a risk of electric shock, and there are no user serviceable parts inside. Opening the case will void your warranty.

Do not use the Digital Picture Frame if conditions could allow condensation to occur, or damage may result.


Your Digital Picture Frame is a complicated electronic device and cannot withstand shock from drops.

Cleaning the LCD screen

Treat the screen gently. The screen on the Digital Picture Frame is made of glass and can be scratched or broken. If fingerprints or dust make the LCD screen dirty, we recommend using a soft, non-abrasive cloth such as a camera lens cloth to clean the LCD screen. If you use an LCD Cleaning Kit sold on the market, apply the cleaning liquid to the cloth. Do not apply the liquid directly to your LCD screen.

Replacing the Remote Control Battery

- 1** — Remove the battery compartment cover by pulling the cover in the direction of the arrow.
- 2** — Remove the battery.
- 3** — Insert the replacement battery taking note of the correct polarity (+/-).
- 4** — Replace the cover.

**Caution:**

- 1. Only use a 3V CR2025 battery.*
- 2. Dispose of used batteries according to local ordinance regulations.*
- 3. Remove the battery when not using the FlashPlayer for prolonged periods.*

Regulatory Compliance

CE Declaration of Conformity

Attestation RSH05080201-1, RSH06080201-2

We declare under our responsibility that the product is in conformity with the following standards

EN55022:1998 (Radio Disturbance requirement of Information Technology Equipment)

EN55024:1998 (Immunity requirement of Information Technology Equipment)

EN61000-3-2:2000 (Limits for Harmonic Current Emission)

As assessed by the following applications standards:

89/336/EEC Electromagnetic Compatibility

This Product is produced by a manufacturing organization on ISO9000 level.

Federal Communications Commission (FCC) Notice (U.S. and Canada Only)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Connections to this device must be made with shielded cables with metallic RFI/EMI connector hoods to maintain compliance with FCC Rules and Regulations. To prevent damage which may result in fire or shock hazard, do not expose this appliance to rain or excessive moisture.

THIS CLASS B DIGITAL APPARATUS MEETS ALL REQUIREMENTS OF THE CANADIAN INTERFERENCE-CAUSING EQUIPMENT REGULATIONS.
FCC Declaration of Conformity

Model Number: DPF-15A1GB.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Commission Fédérale de la Communication (FCC Déclaration)

Cet équipement a été testé et déclaré conforme aux limites des appareils numériques de classe B, aux termes de l'article 15 des règles de la FCC. Ces limites sont conçues de façon à fournir une protection raisonnable contre les interférences nuisibles dans le cadre d'une installation résidentielle. Cet appareil produit, utilise et peut émettre des hyperfréquences qui, si l'appareil n'est pas installé et utilisé selon les consignes données, peuvent causer des interférences nuisibles aux communications radio. Cependant, rien ne peut garantir l'absence d'interférences dans le cadre d'une installation particulière.

Si cet appareil est la cause d'interférences nuisibles pour la réception des signaux de radio ou de télévision, ce qui peut être décelé en fermant l'équipement, puis en le remettant en fonction, l'utilisateur pourrait essayer de corriger la situation en prenant les mesures suivantes:

Réorienter ou déplacer l'antenne de réception.

Augmenter la distance entre l'équipement et le récepteur.

Brancher l'équipement sur un autre circuit que celui utilisé par le récepteur.

Demander l'aide du marchand ou d'un technicien chevronné en radio/télévision.

Toutes modifications n'ayant pas reçu l'approbation des services compétents en matière de conformité est susceptible d'interdire à l'utilisateur l'usage du présent équipement.

Les raccordements à cet appareil doivent être réalisés avec des câbles blindés à protections métalliques pour les connecteurs RFI/EMI afin de maintenir la conformité avec les Règlements et la Législation du FCC.

CET APPAREIL NUMERIQUE DE LA CLASSE B RESPECTE TOUTES LES EXIGENCES DU REGLEMENT SUR LE MATERIEL BROUILLEUR DU CANADA.

Trade Name Model Number



Tested To Comply
With FCC Standards

FOR HOME OR OFFICE USE

End-of-Life Disposal

Your new product contains materials that can be recycled and reused. Specialized companies can recycle your product in order to reuse components of the product and to minimize waste.

Please find out about the local regulations on how to dispose of your old unit from your local municipality.

(For Customers in Canada and U.S.A)

Dispose of in accordance to local state, provincial, municipal or federal regulations. For additional information on recycling in the U.S.A, contact www.eiae.org (Consumer Education Initiative)

Please find out about the local regulations on how to dispose of your old unit from your local municipality.